

MLS-92122 – Precision Linear Stage

The [SMARSHIFT](#) MLS-92122 is a precision linear stage with electromagnetic direct drive. Its compact size simplifies integration into existing systems and leaves enough space for your application. Thanks to its compatibility with the [SMARBOTIC modular system](#), it can be easily combined with the [CLS family](#) and other SmarAct positioners.



Applications

The MLS-92122 has been specifically designed for demanding tasks in industrial manufacturing, including micro assembly, pick-and-place operations, and the alignment and adjustment of components for adhesive processes. Additional application areas include high-precision metrology, such as fly-scan procedures, and ultra-fine additive manufacturing. With its increased load capacity and ability to handle heavier weights, it is ideally suited for applications that require both precision and robustness.

All **SMARSHIFT** products are suitable for use in ambient conditions and inert gas environments, including as helium and nitrogen. Cleanroom options are available.

Travel: 65 mm Dimensions (mm): 92 × 122 × 17 Weight: 640 g

	Mechanical
Travel [mm]	65
Continuous Force [N]	7.5
Peak Force [N]	22
Max. Normal Force [N]	125
Moved Mass (unloaded) [g]	400
Max. Lift Force [N]	3
Dimensions [mm]	92 × 122 × 17
Weight [g]	640
	Material

Base Material	Aluminum, black anodized
	Closed-Loop
Sensor Types	SC
Max. Acceleration (no load) [m/s ²]	45
In-Position Stability [nm]	±5
Sensor Resolution MCS2 [nm]	1
Uni-Directional Repeatability MCS2 [nm]	±40